How to create your ProNav Account
Go to the Main Menu in the ProNav App

≡ **ProNav Angler**

Connect to your ProNav unit ⊕

DISCONNECTED   **0** %
MPH   THRUST

PRO/NAV™

ANCHOR	VECTOR	H. LOCK	ROUTES

CONNECT	SET TO: --- THRUST	STOP	MARK	MAP VIEW

ll cricket LTE   9:23 AM   96%

← ProNav Angler

PRO/NAV
angler

ProNav Marine v3.3.9
Email: support@pronavmarine.com

👤 My Account

◉ Ca[...]

🔧 Control Settings

📡 Network Settings

⇄ Revert to Pedal

✏ Buy Now

❓ Tutorials

🖼 Get In Touch

⬆ Upgrade Firmware

🛠 Unit Diagnostics

✴ Disconnect

Connect

0.0 MPH   DIS

PR

⚓ ANCHOR

↑ VECTO

SET TO:

THRUST

✴ CONNECT

Press "Register"

← ProNav Angler

PRO NAV
angler

Email

Password

LOGIN   REGISTER

FORGOT PASSWORD

Enter your information then press "Register"

← ProNav Angler

PRO NAV
angler

johndoe@gmail.com

JohnDoe#123

JohnDoe#123

REGISTER

Press "Close" in the Register Success popup box

ProNav Angler

PRO/NAV angler

Email

Password

Register Success
Login to Sync Account data

Close

FORGOT PASSWORD

Enter your username and password you just created then press "Login".

← ProNav Angler

PRO/NAV
angler

johndoe@gmail.com

JohnDoe#123

LOGIN

REGISTER

FORGOT PASSWORD

Account successfully created.

← ProNav Angler

Last data backup/synch was on 10-01-2020
09:11 EST

SYNCH DATA NOW

Note: You can now login to
multiple devices and sync your
data between all devices

LOGOUT

A popup box will show up indicating your data is syncing

← ProNav Angler

Last data backup/synch was unknown

SYNCH DATA NOW

Sync Routes

Retrieving Account Routes

LOGOUT